

CYCOM® X5320

Innovative Approach to Out-of-Autoclave Processing

September 9, 2008

maintaining the data needed, and of including suggestions for reducing	election of information is estimated to completing and reviewing the collect this burden, to Washington Headquuld be aware that notwithstanding an OMB control number.	ion of information. Send comments arters Services, Directorate for Info	regarding this burden estimate or rmation Operations and Reports	or any other aspect of th , 1215 Jefferson Davis l	is collection of information, Highway, Suite 1204, Arlington	
1. REPORT DATE SEP 2008		2. REPORT TYPE N/A		3. DATES COVERED		
4. TITLE AND SUBTITLE				5a. CONTRACT	NUMBER	
Innovative Approach to Out-of-Autoclave Processing				5b. GRANT NUMBER		
				5c. PROGRAM E	LEMENT NUMBER	
6. AUTHOR(S)			5d. PROJECT NUMBER			
			5e. TASK NUMBER			
			5f. WORK UNIT NUMBER			
7. PERFORMING ORGANIZATION NAME(S) AND ADDRESS(ES) \mathbf{WPAFB}			8. PERFORMING ORGANIZATION REPORT NUMBER			
9. SPONSORING/MONITORING AGENCY NAME(S) AND ADDRESS(ES)			10. SPONSOR/MONITOR'S ACRONYM(S)			
			11. SPONSOR/MONITOR'S REPORT NUMBER(S)			
12. DISTRIBUTION/AVAIL Approved for publ	LABILITY STATEMENT ic release, distributi	on unlimited				
13. SUPPLEMENTARY NO The original docum	otes nent contains color i	mages.				
14. ABSTRACT						
15. SUBJECT TERMS						
16. SECURITY CLASSIFICATION OF:			17. LIMITATION OF ABSTRACT	18. NUMBER OF PAGES	19a. NAME OF RESPONSIBLE PERSON	
a. REPORT unclassified	b. ABSTRACT unclassified	c. THIS PAGE unclassified	UU	11	ALSI ONSIBLE I ERSON	

Report Documentation Page

Form Approved OMB No. 0704-0188

Agenda

- Introduction
- Problem Statement
- Cycom X5320
- Potential Value Proposition
- Solicit input on the interest for Out-of Autoclave



Introduction-Cycom X5320 prepreg

CEM is experienced and capable with OOA

- Material Science through chemistry and understanding
 - Balanced cure cycles to customer requirements
 - Reduce porosity; control viscosity
 - Tack life and total out-time
 - Maximize mechanical properties that drive key design elements
- Technical Service Support Global tech support of material selection, lay-up, tooling, and assembly
- Application Engineering PRIM, Automation (AFP, ATL) BMI & toughened epoxy




Problem Statement

- Progress technology/capability from secondary to primary structure
- Provide material system capable of prototype or production needs

Gaps Today	Specific Limitation	<u>Target</u>
Mechanical performance	secondary structure	primary
Porosity	<4%	<1%
Tack/Handling	<10 days	30 days
Component size	geometry and dimension limited	unlimited
Versatility	lengthy low temp cure varying properties w/cure poor green strength	<12hr initial consistent excellent



Attacking problem through material science




- Fundamental material science approach
- 977-3 technology
- Critical in-depth understanding of key OOA characteristics of flow, gel, impregnation, resin advancement
- Versatile, robust manufacturing cure cycle options – providing necessary green strength
- Supported by in-application engineering

Cycom X5320 Introduction

<u>Breakthrough OOA material – addresses primary structure needs</u>

- Legacy military fighter epoxy autoclave mechanical properties with OOA processing
- Large, primary structure component processing
 - Porosity
 - Hot/Wet
- Tailorable handling properties to meet hand-layup and automation part manufacturing
- Prototype parts to high-rate production capable
- Flexible cure cycles providing robust degree of cure with final resin cross-linking

	Current		
	Autoclave	OOA	<u>X5320</u>
Large scale components	×	V	
Primary structure	V	×	
Continuous flow process	×	V	
Hot/Wet strength	V	×	
Eliminates porosity	V	×	
Automation	V	×	



Properties of X5320 limited and preliminary data collection

Properties	977-3 IM fiber	X5320 IM fiber
OHC (220F/Wet) [0/90]3s; ASTM D6484; qty=8	39.3 ksi	42.3 ksi
Tg (Wet) DMA Storage Mod; [0]10	303°F	310°F
OHT (-65F/Dry) [+,0,-,90]3s; ASTM D5766; qty=8	65.4 ksi	75.1 ksi
CAI [+,0,-,90]4s; SRM02R94; qty=8	25.2 ksi	29.6 ksi
Solvent Resistant	Pass	Pass
Initial Cure Temp	355F (autoclave)	200F/16 hours (VBO)

Product Portfolio

Unidirectional Tape

- X5320 T40-800B 145 gsm/33% resin content, 49" width
- X5320 T40-800B 290gsm/33% resin content, 49" width

Fabric

X5320 WT650-35 3K-8HS 48" width, 36% resin content

Non-Carbon Forms

- X5320 4581Q-9837 38" DP 35% resin content
- X5320 108 50" width, 50% resin content
- X5320 60001 50" width Peel Ply



Ancillary products

Material	Recommended	Target Properties
Film Adhesive	FM300-2K or FM209M	FWT (220F/Wet) Equivalent to FM300 (-65F:800psi, RT:700psi, 250f:500psi)
Foaming Adhesive	FM490A	Similar to FM404A. Passes expansion requirement at 200F of 200%.
Peel Ply	X5320 Peel Ply	Compatible with resin and removes cleanly from part
Syntactic Core	FM381	Density:40 pcf, FWT similar to FM381
Surfacing Film	SM 905M	Clean surface; no surface porosity



Out-of-Autoclave Value Proposition

Performance

- Address **porosity** and **mechanical performance** which have historically limited Out-of-Autoclave materials to secondary structures
- **Geometrically limited** due to part quality of autoclave processing (resin rich, thin out, etc)
- Unitized structure design
- Ability to support rapid, small volume aircraft demonstrations & insertion into **production rates**

Cost

- Alternative tooling design concepts
- Part count reduction addressing legacy black aluminum designs
- **Supply-base capability & expansion**
- **Lower capital costs** for further composite application adoption
- **Qualification** serves demonstration articles and production

Discussions/Feedback

- Material characteristics
- Material product forms
- Industry Material Specifications interest, approaches
- Processing constraints, desires
- Database considerations
- Tooling approaches, concerns
- Equipment requirements ovens, vacuum sources, other heat sources
- Challenging part features for producibility evaluation/scale
- Applications and related constraints/issues
- Variability, robustness
- Further interest?

Please complete the questionnaire provided... your input is essential!

